


Thanks for bringing Burrow into your home

Everything we make is incredibly simple to set up, including your new bed. You won't need any tools, but an extra set of hands to help flip will be useful.

Before you start, clear out the space where your bed will go. If you plan to put a rug under your bed, it's best to place it on the floor now, and adjust it before you put the mattress on top.

For the bed frame




2

Important note: you're going to start with the bed frame upside down.


Feel free to contact support@burrow.com with any specific questions!

For the headboard




1

Unpack the box and place the pieces, upside down, in their approximate positions: the side rails on the left and right, the head rail at the top, and the foot rail at the bottom. You can identify the bottom of each rail by the wood supports underneath the lip.



2


Slide the rails together and insert the teeth on the side rails into the head and foot rails. The interior lip of the side rails will nest underneath the lip of the head and foot rails.



3


3

Screw a leg into each of the four corners to hold each of the rails together.




4

With a partner, gently flip the bed frame so that it's right-side up, and rest it back on the ground.



5

Screw the center support leg into the center support rail.



6

Rest the center support rail into the notches at both ends of the bed frame. **If you don't have a headboard, skip ahead to Step 10.**

